























































mounts



 SR019 19mm ID	 SR032 32mm ID	 SR034 34mm ID	 SR045 45mm ID	 SR050 50mm ID	 SM001 5/16 UNF	 CM006 6mm	 CM007 10mm	 CM033 8mm
 CM001 Audi	 CM008 Fiat/Lada	 CM009 Fiat 127/128	 CM010 Fiat 124/125/132	 CM013 Peugeot/Citreon	 CM022 Audi	 CM023 Honda Civic		
 CM024 Universal	 CM036 Audi 76-82 100	 CM038 Saab	 CM041 Volvo	 CM042 Fiat	 CM055 Honda - All Models	 CM071 Holden VT 2 Hole		
 CM081 Mercedes	 CM084 Renault	 CM085 Alfa	 CM095 Citreon	 CM097 Mazda	 CM099 Mercedes	 CM101 Nissan/Subaru		
 CM106 Saab	 CM108 Toyota - All Models	 CM115 BMW	 CM117 Honda	 CM122 Mitsubishi	 CM123 Mercedes	 CM159 Renault		
 CM166 Toyota Carina	 CM171 Toyota Hilux	 CM172 Toyota Lancruiser	 SM005 Triumph/Jaguar	 SM027 Universal	 SM035 Ford Cortina	 SM044 Allegro		
 SM050 Ford Escort	 SM052 Daimler/Jaguar	 SM053 Daimler/Jaguar	 SM054 Ford/Opel	 SM070 Holden Commodore	 SM459 Holden Commodore	 SM800 Honda Prelude		
 SM805 Ford Falcon EA	 SM809 Holden VN - VR	 SM854 GM/Opel	 UB003 Universal	 UB005 Universal	 UB022 Universal	 UB333 3 metre		

autobend

Branches in Auckland and Christchurch
 Ph 0800 288 623 Fax 0800 737 979
 sales@autobend.co.nz | www.autobend.co.nz

mufflers

headers

laser cutting

tube bending

new mounts



 <p>CM003 Mazda 3 / Ford Focus</p>	 <p>CM072 Commodore</p>	 <p>CM079 Toyota</p>	 <p>CM103 Nissan mount</p>	 <p>CM111 GM mount</p>	 <p>CM137 Ford mount</p>
 <p>CM223 Toyota mount</p>	 <p>CM230 Toyota Prado</p>	 <p>CM232 Toyota mount</p>	 <p>CM237 Toyota mount</p>	 <p>CM330 BMW / Universal</p>	 <p>CM402 Daewoo mount</p>
 <p>CM615 Ford mount</p>	 <p>CM705 GM mount</p>	 <p>CM712 VW Golf</p>	 <p>CM733 MG / Universal</p>	 <p>CM750 GM mount</p>	 <p>CM811 Hyundai mount</p>
 <p>CM813 BMW / Universal</p>	 <p>CM815 Jaguar rear mount</p>	 <p>CM817 BMW / Universal</p>	 <p>CM821 BMW / Universal</p>	 <p>CM825 BMW / Universal</p>	 <p>CM829 BMW / Universal</p>
 <p>CM913 Universal</p>	 <p>CM930 Mitsubishi mount</p>	 <p>SM004 Universal</p>	 <p>SM007 Mini / Universal</p>	 <p>SR064 64mm ID</p>	 <p>HBS001 13mm OD x 42mm HBS002 16mm OD x 67mm HBS003 13mm OD x 67mm</p>

autobend

Branches in Auckland and Christchurch
 Ph 0800 288 623 Fax 0800 737 979
 sales@autobend.co.nz | www.autobend.co.nz

mufflers

headers

laser cutting

tube bending